

Adjustable Air Ride Ram 2500 Rear Instructions

Make sure the key is out of the ignition and no power is on.

Spray a little WD40 or similar lubricant on the factory Link ends before removal.

1. Jack up the rear and locate the ride height sensor arms. They are connected to the end of the differential close to the brakes.
2. Remove the stock Links by clamping on a small set of vice grips & twisting it off. Once 1 side is off the other comes off easily by bending it backwards. Still be gentle enough as to not break the sensor arm.
3. Set new Adjustable Links to equal lengths. **Lengthening the Link from the factory length will raise the vehicle.** Each 5mm longer then stock will lower approx. $\frac{3}{4}$ - 1 inch. Don't have to lock them tight just snug.
4. Install with long end up. **Make sure the sensor arm is pointing the same direction as before.**

Start the vehicle, move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust. Just remove 1 side of the Link by using a 10mm wrench and give it a few turns. Usually 2 turns is about a $\frac{1}{4}$ inch in height.

Always looking to add more pictures of vehicles to the site. If you would like yours on there they can be uploaded from the site or send them to john@adjustableairride.com

Thank you for the purchase. If you have any questions please don't hesitate to ask anytime via phone or Email.

John Vranic

604-780-7734

www.adjustableairride.com