## Adjustable Air Ride Dodge Ram Raise Instructions

Put the vehicle to the highest setting. Make sure the key is out of the ignition and no power is on.

## **Front:**

- 1. Look straight inside the wheel well & you will see the factory ride height sensor Link.
- 2. Simply twist & pull the factory Link off.
- 3. **Shortening** the Link from the factory length will raise the vehicle. Each 5mm variance from stock will adjust the vehicle approx <sup>3</sup>/<sub>4</sub> 1".

## Rear:

- 1. The rear link is connected right in front of the rear tires.
- 2. Remove the rear the same way as the front. Will just pop off.
- 3. **Lengthening** the Link from the factory length will raise the vehicle. Works the same as the front.

Start the vehicle, raise it up and down and move it forward and back to get the suspension active to the new settings. If you are not happy with the height you can easily re-adjust each Link. Just remove 1 side of the Link and give it a few turns. Usually 2 turns is about a ¼ inch in height

Depending how high you make the vehicle a wheel alignment may be required to reduce tire wear.

Always looking to add more pictures of vehicles to the site. If you would like yours on there they can be uploaded from the site or send them to john@adjustableairride.com

Thank you for the purchase. If you have any questions please don't hesitate to ask anytime via phone or Email.

John Vranic 604-780-7734 www.adjustbaleairride.com



Front Stock Link



Rear Stock Link





Adjustable Link